

MINIDVD TO DVD

Turn the JVC player, the TV and the MiniDV Panasonic Player on





Insert a blank DVD in the JVC and the MiniDV tape in the Panasonic MiniDV Player

Play the MiniDV tape



Use the AUX button on the remote until you see the tape show on the TV



JVC
RM-SDRMV100A
DVD VIDEO RECORDER

Play the MiniDV tape until you find the beginning of your recording.

Pause the MiniDV tape at the beginning of your recording.

Click on the Record button on the JVC player and Play the MiniDVD tape. The JVC player need to be in DVD mode. You are recording now.



If you want to finish the recording before the end of the tape, press PAUSE on the JVC player, and then STOP on the MiniDV tape



It is very important to Finalize the DVD when you are done so it can be played on other players as well



The JVC Player has to be on DVD mode. If it is not, click on the DVD/VCR Button



Click HOME on the Remote

Find Easy Menu on the screen navigating with the arrows on the Remote. Select Disk Manager and click Enter on the remote.

A screen like this
will appear....



Select Finalize

Enjoy your DVD.